


GAME CLOCK/VISUALS CONSOLE



TEAM A (player bench to left of scorebench when facing the court) – use **Yellow** buttons to record Team A's Score, Team Fouls, Time Outs

TEAM B (player bench to right of scorebench when facing the court) – use **Orange** buttons to record Team B's Score, Team Fouls, Time Outs

GREEN BUTTONS:

RESET TIMER – resets time to 10 minutes for beginning of each quarter

ADJUST + MIN and **- MIN** – add time on or take time off in increments of 1 minute, use at quarter time and half time to add 1 minute or 2 minutes for the interval breaks.

START – starts the game clock

HOLD – stops the game clock

BLUE BUTTONS:

SIREN – to get referees attention to call subs or time outs

POSSESSION ARROW – indicates which team has advantage of next possession arrow

ERROR -1 PREV – use to correct errors, it reverses previous action, eg if an extra score on a team, press this button to remove it

+1 P – indicates current period (quarter) of the game. Set this at the beginning of the quarter.

RESET NEW GAME – resets the scoreboard for a new game

RESET FOULS T/OUTS – press once at end of 1st and 3rd quarters and team fouls will be reset, press twice at half time to reset team fouls and time outs

TIME OUTS START STOP – this will count down 60 secs for time outs, a siren will go off when it gets to zero

